FOR SONY FX3/FX30 TILTIFIC TO THE TOTAL CAMERA CAGE TO THE CAMERA CAGE TO THE TOTAL CAMERA CAGE TO THE TOTAL CAMERA CAGE TO THE TOTAL CAMERA CAGE



[DISCLAIMER]

Thank you for purchasing a TILTA product.


Before using this product, please carefully read this document to ensure that the product has been set up correctly. The final interpretation of this document and all related documents for this product belongs to TILTA. For updates, please visit the official website at www.tilta.com for the latest product information. TILTA reserves the right to modify any information in this manual at any time without prior notice and without assuming any


By using this product, you are deemed to have carefully read the disclaimer and warnings, understood, agreed, and accepted all the terms and content of this statement. You promise to take full responsibility for the use of this product and any consequences that may arise. You commit to using this product only for legitimate purposes and agree to this term as well as any related regulations, policies, and guidelines set by TILTA.


TILTA is not responsible for any damages, injuries, or legal liabilities caused directly or indirectly by the use of this product. Users should follow all safety guidelines mentioned in this document, including but not limited to those mentioned. Despite the above provisions, consumer rights are still protected by local laws and regulations and are not affected by this disclaimer.

TILTA is a trademark of Shenzhen TILTA Technology Co., Ltd. and its affiliated companies. Product names, brands, and other trademarks appearing in this document are trademarks or registered trademarks of their respective companies.

[FULL CAGE OVERVIEW]







3/8"-16 Thread with Locating Points

15 Camera Mounting Thread

(For mounting oboard microphones, LEDlights, and wireless video transmitters.)


R 1/4"-20 Thread M Shoulder Strap Receiver

(Top Plate)

1/4"-20 Thread


1 3/8"-16 Thread

M4 Thread







Cold Shoe Receiver







DETAILS >>














- NATO Receiver (Top Plate)
- M3 Thread
- 1/4"-20 Thread with Locating Points M3 Thread
- cable clamp.) Camera Mounting Thread
- (Side Arm) NATO Rail (Side Arm)
- M3 Thread
- Wrist Strap Receiver
- 1/4"-20 Thread with Locating Points
- Camera Mounting Thread
- (Bottom Plate)
 - Flat Head Screwdriver (Stores under the camera cage can be replaced by a coin.)


Camera Mounting Thread

INSTALLING THE FULL CAMERA CAGE










(1)




14 FULL CAGE CAN TRANSITION TO HALF CAGE




1. In the full cage mode, the ① L-Bracket side arm can be removed to switch the full cage to a half cage.

2. Place the camera into the 2 half cage, take out the 3 flathead screwdriver and insert the screw into the mounting thread at the bottom of the cage

3. Tighten the 4 flathead screw on the side arm of the cage to secure the camera cage.



[ASSEMBLING THE CABLE CLAMP]



Install ① the cable clamp onto the M3 thread on the upper left side arm of the cage, tighten ② the screw to complete

FOR SONY FX3/FX30 TILTIFIED TO THE TENT T

感谢您购买TILTA产品。

使用本产品之前,请仔细阅读本文以确保已对产品进行正确的设置。本文档及本产品所有相关的文档最终解释权归TILTA所有。如有更新,请访问www.tilta.com 官方网站获取最新的产品信息。TILTA保留随时修改本手册中任何信息的权利,无需提前通知且不承担任何责任。

- 旦使用本产品,即视为您已经仔细阅读免责声明与警告,理解、认可和接受本声明全部条款和内容。您承诺对使用本产品以及可能带来的后果负全部责任。 您承诺仅出于正当目的使用本产品,并且同意本条款以及TILTA制定的任何相关条例、政策和指引。

M

12 3/8定位螺纹孔

🚹 机身固定孔(顶板)

7マギロ女口 [可接上手提/麦克风/灯光/ 图传/监视器支架等配件]

图 1/4螺纹孔

🛛 肩带接口

冷靴接口

7 1/4螺纹孔 IR M4螺纹孔

图 3/8螺纹孔

📶 机身固定孔(底部)

[可磁吸附于底部的拆卸工具, 同时可用硬币替换使用]


27 一字螺丝扳手


TILTA对于直接或间接使用本产品而造成的损坏、伤害以及任何法律责任不予负责。用户应遵循包括但不限于本文提及的所有安全指引。


即使存在上述规定,消费者权益依然受当地法律法规所保障,并不受本免责声明影响。


TILTA是深圳市铁头科技有限公司及其关联公司的商标。本文出现的产品名称、品牌等均为其所属公司的商标或注册商标。

2 [认识全笼]










- Ⅲ 1/4定位螺纹孔
- M NATO滑条(顶板)
- **IR** M3螺纹孔 [可安装镜头转接环支撑]
- 🛮 1/4定位螺纹孔
- M3螺纹孔 [可安装线夹等配件]
- **III** 机身固定孔(侧臂)
- ₩ NATO滑条(侧臂)
- III M3螺纹孔
- 🖪 腕带接口
- Ⅲ 1/4定位螺纹孔
- 机身固定孔(侧臂)

细节展示 >>




冷靴/NATO [顶板-顶部] -体化设计, 可外接上手提/侧手柄

上顶板可单独拆卸,拆卸后可安装原装上手提。



[顶部] 可接麦克风/灯光/ 图传/监视器支架




L板可单独拆卸, 根据半笼走势。






1. 将摄影机装入FX3全笼①, 再取出底部 一字扳手②,将螺丝装进笼子底部的机器


2. 将③一字螺丝锁紧于笼子两侧, 以固定 机身;摄影机顶部可安装④上顶板,拓展 更多配件。









4 [全笼可切换为半笼]



- 1. 全笼状态下可拆卸①L板侧臂, 将全笼切换为半笼。
- 2. 将摄影机装入②半笼, 再取出③一字扳手, 将螺丝 装进笼子底部的安装孔。
- 3. 将④一字螺丝锁紧于笼子侧臂, 以固定机身。





将线夹①安装在笼子右侧臂上方的M3螺纹孔上,拧紧螺丝②完成装配。